

MyCROCEMENT™ — Install at a Glance

1. Evaluate Surface

Confirm the surface is stable. Porous vs non-porous classification not required.

2. Prep & Repairs

Clean, remove loose material, make minor repairs, ensure flatness.

3. Prime & Reinforce

Apply primer evenly. Install mesh where required and fully embed.

4. Base Coats

Apply two thin base coats. Lightly sand between coats.

5. Finish Coats

Apply two thin finish coats. Control texture and movement.

6. Seal & Protect

Apply sealer in multiple thin coats. Observe cure times.